

**SUPERMARK LABELS**  
**APPLICATION PROCEDURE**  
**USING **SUPER**tubes OF WHITE COMPOUND**

**Please read before commencing marking**

- 1 The SUPERMARK system is very simple to carry out if the instructions are followed.
- 2 All items to be marked should be clean and dry, and best results are on flat/smooth surfaces.
- 3 Peel off the backing paper from the rear of the label.
- 4 Make sure the label is firmly in place on the item to be marked by using the backing paper previously removed from the label to smooth it out (*make sure you use the non-greasy side of the backing paper*). Rub down firmly around the edges and across the dot-matrix holes, to expel any air.
- 5 *Please note that you need only a small amount of the marking compound, enough to fill each of the matrix holes that make up the marking message/code.*

**PLASTIC & BAKED PAINT FINISH SURFACES**

**Note:** The WHITE compound in the large ‘SUPERtubes’ is designed primarily for use on surfaces that are BLACK or VERY DARK, where it will show up more visibly than the blue compound. It is weaker than the blue plastic marking compound in the small tubes and may not make as deep an ‘etch’ in some surfaces. We therefore recommend using the blue compound in small tubes wherever possible.

- Squeeze out a small amount of the compound onto the WHITE SPREADER provided.
- Spread compound onto the label, making sure that each of the matrix holes is filled with the white compound so as to achieve an even marking.
- After 30 seconds, dab off any excess compound with a clean, dry paper kitchen towel, then remove the protective overlay on the front of the label by picking up from the top edge where there is a strip of red colour. BE CAREFUL NOT TO DAMAGE THE LABEL ITSELF).
- ***LEAVING THE PROTECTIVE OVERLAY ON FOR LONGER WILL NOT IMPROVE THE MARKING - IN FACT, THE MARKING MAY BECOME ‘FUZZY’.***

**DO NOT TOUCH THE MARKING** - it will remain wet and soft for several hours and will only harden completely after 48 hours.

- *Do not allow children to use the marking compounds.*
- *Keep tubes of compound in a cool place, preferably in a locked cupboard.*
- *Backing paper, overlays and tubes, after use, should be disposed of carefully.*
- *DO NOT EAT, DRINK OR SMOKE WHEN USING ANY COMPOUND.*
- *IF ANY COMPOUND SHOULD COME INTO CONTACT WITH SKIN, IT SHOULD BE WASHED OFF WITH SOAP AND WARM WATER AS SOON AS POSSIBLE.*

Have you read the detailed instructions above? If followed carefully, you will have a successful marking each time. Remember that the mark is permanent, so any mistake cannot be altered.

Each SUPERTube of marking compound contains sufficient to mark more than 50 items. We provide you sufficient compound to mark the number of labels ordered.

Once opened, the tube has a shelf life of several months if kept with the cap tightly on and in a cool, dark place.

**If you have any queries, please telephone our helpline on: 2519 4356**