

APPLICATION PROCEDURE USING **BLUE COMPOUND IN BOTTLES** ON PAINTED METAL OR WOOD SURFACES

(Blue compound in bottles is weaker than the Blue compound in tubes and may produce a better result on painted metal and wood surfaces).

Please read before commencing marking

The marking procedure is very simple if the instructions are followed. All items to be marked should be clean and dry, and best results are on flat, smooth surfaces.

USING WITH SUPERMARK LABELS:

- Remove backing paper from label and apply label to surface.
- Make sure the label is firmly in place on the item to be marked, by using the backing paper removed from the label to rub down firmly and smooth it out. Press down firmly around the punched holes (your ID mark).
- Using the brush in the cap, put some compound onto the label, to the left of the punched letters. Then using the plastic spreader, spread the compound across and into the holes, ensuring all the holes are filled with the blue. ***NOTE: Do NOT apply too much compound - only sufficient to fill the holes. Remove any excess compound around the mark or on other areas of the label using the spreader.***
- Wait until the compound starts to dry (begins to look 'dull') – usually around 30 seconds or so - then remove the protective overlay by carefully lifting from the top (from the left with small labels) where it is coloured red. Take care not to damage the label when lifting the overlay.
- ***DO NOT TOUCH MARK FOR AT LEAST 24 HOURS*** (mark will feel dry to the touch after approx 6-8 hours but will take about 2 days to harden completely).

IMPORTANT NOTES

- Do not allow children to use the marking compounds.
- Keep the compound in a cool place and preferably in a locked cupboard.
- After use, label overlays and compounds should be disposed of carefully.
- **DO NOT EAT, DRINK OR SMOKE WHEN USING ANY COMPOUND.**
- Protect eyes and hands when using Marking Compounds.
- If the Compound comes into contact with skin, it should be washed off with soap and warm water or an alcohol swab as soon as possible.
- If the Compound comes into contact with eyes do NOT rub. Rinse immediately with plenty of water and obtain medical attention, showing Compound container to medical staff.
- If Compound is swallowed, do NOT induce vomiting. – Drink water and seek medical advice immediately, showing Compound container to medical staff.

Each bottle of Marking Compound contains sufficient to mark approx 40-50 labels – we provide more than sufficient to complete your marking as per the labels ordered. The compound has a shelf life of at least 6 months when kept in a cool, dark place, with the top firmly closed.

Have you read the detailed instructions above? If followed carefully, you will have a successful marking each time. Remember that the mark is permanent, so any mistake cannot be altered.